



Optical Fiber Arc Fusion Splicer

Read this user manual carefully before running K33A

SWIFT K33A

USER MANUAL

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Device Type	Notification
A Class Device (Broadcasting and communication device, commercial use)	Users need to understand that this device(A Class) has obtained EMI(Electromagnetic compatibility) and been designed to be used in places other than home.

Telephone 042 671 5607~8

Homepage www.uclswift.com

E-mail saleskorea@uclswift.com



TABLE OF CONTENTS

I. FOR YOUR SAFETY	3
II. SPECIFICATIONS	7
2.1 General specifications	7
2.2 Components	8
III. PRODUCT DESCRIPTION	10
3.1 Function Buttons	10
3.2 Part name of Swift K33A	11
IV. OPERATION	25
4.1 Supplying power to the Swift K33A	25
4.2 Turn on the Swift K33A	29
4.3 Installing the sleeve loader / cooling tray	30
4.4 Inserting the fiber into the sleeve	31
4.5 Optical fiber cleaning and stripping	31
4.6 Cleaving the fiber	32
4.7 Load the fiber to the Swift K33A	33
4.8 Splice	34
4.9 Swift K33A Sleeve-Heater part	35
4.10 Separation of connected optical fiber	37
4.11 Heating for protecting sleeve	37
V. MAINTENANCE OF SPLICE QUALITY	38
5.1 Cleaning and Inspection before splice	38
5.2 Regular cleaning and inspection	40
VI. MENU	46
6.1 Splice	55



6.2 Sleeve Heater	63
6.3 Auto Stripper menu	67
6.4 History	70
6.5 Option	72
6.6 Calibration	76
6.7 Electrode	80
6.8 Setting	83
6.9 Information	87
VII. ERROR MESSAGE	90
7.1 Too Dirty Fiber	90
7.2 Replace the optical fiber	90
7.3 Too long Fiber	91
7.4 Fiber Over Angle	91
7.5 Loss is higher	92
7.6 Optical fiber is thin	92
7.7 Optical fiber is thick	92
7.8 Core bubble error	93
7.9 Error on cut surface on left, right or both	93
VIII. HOW TO DEAL WITH SPLICING PROBLEMS	94
8.1 When the splice loss is too high	94
8.2 Abnormal operation of arc fusion splicer	95
IX. Q & A	96
9.1 Power	96
9.2 Splice	97
9.3 Sleeve heater	98
9.4 The others	99
X. WARRANTY PERIOD AND SERVICE	100
10.1 Information required for repair	100
10.2 Transport	101
10.3 Repair	101



I. For your safety

The Swift K33A is designed to satisfy the user's convenience for both outdoor and indoor use, allowing the operation easy and simple. Still, we strongly recommend our customers to read this user manual carefully prior to running the Swift K33A in order to prevent any accident and breakdown because improper handling may cause danger. This user manual provides all the necessary information to ensure splicing safely.

Keep this User manual with the device at all times.

UCLSWIFT Co., Ltd is not liable for any personal injury, any physical loss and damage to device caused by inappropriate use or unauthorized modification of the equipment.

Warnings

Please, turn off the Swift K33A and disconnect the AC power cord from the AC adapter inlet or the wall socket immediately and contact UCLSWIFT Co., Ltd. If any of following incidents occurs while operating.

- Fumes, odor, noise or overheating.
- Liquid or foreign substances fall into the device.
- The splicer is dropped or damaged.

Use the supplied power cord with the Swift K33A only. Using an improper AC power cord may cause fire, electric shock or personal injury.

DO NOT touch the electrode when the Swift K33A is on. The high voltage and temperature generated by electrode may cause electric shock or burn.

Connect the supplied AC power cord to the battery. Check to ensure no dust or foreign substance on the AC plugs before connecting it. Unsafe connection may cause the fumes, fire or damage to the Swift K33A and result in serious personal injury or death.

Warnings

Apply correct voltage. The correct input AC power to the adapter is AC 100-240V and 50-60Hz. Abnormally high AC output voltage or irregular frequencies are often generated by AC generator. Please measure the AC output voltage with a circuit tester. Since abnormal high voltage and frequencies may result in serious electric shock, injury, death or damage to the equipment, it is important that regularly check the generator before use. DO NOT excessively pull, amend, misuse or apply heat to the AC power cable. Using a damaged power cable may result in fire or personal injury. Connect 3-core AC power cord. DO NOT use 2-core, cable and plug.

DO NOT touch the AC plugs, AC power cable or the Swift K33A with wet hands. It may cause an electric shock.

DO NOT disassemble the AC adapter, battery or the Swift K33A. Any modification may cause fire, electric shock or personal injury.

When using the battery, follow instructions below.

- Using battery other than in the package or provided by UCLSWIFT Co., Ltd may cause fumes, damage to the device, burn, serious injury or even death.
- DO NOT throw the battery into fire or an incinerator.
- DO NOT charge the battery near a flame.
- DO NOT apply excessive shock to the battery.
- If the battery is not fully charged or the green LED is not turned on in about two hours, stop charging immediately and contact UCLSWIFT Co., Ltd. DO NOT put anything on the AC adapter while charging.

Use the supplied AC adapter (F1-1) at all times. DO NOT use other type of AC power cord and the battery. Excessive electric current may cause damage to the machine and personal injury.

DO NOT run the Swift K33A near flammable liquid or explosive gas storage. The electric arc of the Swift K33A may cause fire or explosion.

Warnings

DO NOT clean the Swift K33A using compressed air or gas.

Please check the shoulder belt before transporting. Transporting the case with a damaged shoulder belt, it may cause the damage of the Swift K33A and the personal injury.

Make sure to wear protective glasses while performing splicing works. If the fiber fragments come into contact with the eye or skin, it can be extremely dangerous.

DO NOT operate the Swift K33A at a high temperature or near heat, otherwise personal injury or damage to the device may occur.



: EXTREMELY HOT



: DO NOT SPRAY FREON GAS



: CAUTION HIGH VOLTAGE

Cautions

DO NOT touch the sleeve heater or the sleeve during or immediately after heating them. The hot surface may cause skin burn.

DO NOT place the Swift K33A in an unstable or unbalanced position. The machine may fall, causing injury or damage to the Swift K33A.

The Swift K33A is precisely adjusted and aligned. DO NOT allow the unit to receive a strong impact. Use supplied carrying case for its transportation and storage. The carrying case protects the Swift K33A from damage, moisture, shake and shock during storage and transportation.

Replace the electrodes in a timely manner and maintain them as instructed below.

- Use only a specified electrode.
- Place a new electrode in the correct position.
- Replace the electrodes as a pair.

Incompliance with above instructions may cause abnormal arc discharge, resulting in damage to the machine or degradation in splicing performance.

Use no chemicals other than ethyl-alcohol (96% or greater) to clean the objective lenses, V-groove, V-block, LCD monitor and body of the Swift K33A. Otherwise, blurring, discoloration, damage or performance deterioration may occur. The Swift K33A requires no lubrication. Oil or grease may degrade its performance and damage the equipment.

DO NOT store the Swift K33A in a place where temperature or humidity is high. Damage to the machine may occur.

Technical aspects of Swift K33A should be inspected by a qualified expert. When ignoring this, it may incur fire or electric shock. Discuss with UCLSWIFT Co., Ltd to use the service.

II. Specifications

2.1 General specifications

Subject	Description
Fiber alignment	IPAAS Core Alignment
Applicable fibers	SM(G.652), MM(G.651), DS(G.653), NZDS(G.655), SM(G.657 A1, A2/B2, B3), SM(G.654E)
Fiber count	Single fiber
Applicable fiber dimensions	Cladding diameter: 80~150 μ m, Coating diameter: 100 μ m - 3mm
Fiber cleave length	250 μ m: 5~16mm, 900 μ m: 8~16mm
Splicing modes	Splice mode: 300, Heat mode: 100, Strip mode :50
Average splice Loss	SM: 0.02dB, MM: 0.01dB, DS: 0.04dB, NZDS: 0.04dB
Return loss	> 60dB (Typical)
Splicing time	Typical 6 sec. (Quick Mode)
Splice loss estimate	Available
Sleeve heating time	9 sec (IS-45 Sleeve, IS-45 mode), 13 sec (IS-60 Sleeve, IS-60 mode)
Applicable protection sleeve	32mm, 40mm, 60mm (Fiber) / 28mm or 32mm (Connector)
Storage of splice result	The last 10,000 results to be stored in the internal memory. (Image 10,000 results)
Tension test	1.96N ~ 2.25N
Operating conditions	Altitude: 0~5,000m above sea level, Temperature: -10 $^{\circ}$ C~50 $^{\circ}$ C, Humidity: 0~95%, Wind: 15m/s, Non-condensing, Dust proof, Water proof,



	Shock proof
Storage conditions	Temperature: -40°C~80°C, Humidity: 0~95%
Dimensions	136(W) x 215(L) x 137(H)mm (Excluding bumper)
Weight	2.45kg (Including battery)
Viewing method and display	Two CMOS cameras and 5.0-inch color LCD monitor with Electrostatic touch screen
Fiber view and magnification	X/Y: 200X, Max 670X
Power supply	100 ~ 240V AC
Battery life with heat-shrink	Typical 230 cycles (6000mAh)
Electrode life	Up to 18,000 splices
Terminals	USB, External Power(DC 12V available for car cigar jack)

2.2 Components

2.2.1 Standard items

Description	Model No.	Quantity
Arc Fusion Splicer	SWIFT K33A	1
User guide	Download from UCL Swift Website	
Cooling Tray	-	1
Transporting Case	Hard Case	1
Battery	K3360(6000mAh)	1
AC Adapter	100-240V	1
Tool box	-	1







2.2.2 Optional items



Description	Model No.
Battery	K3360(6000mAh)
Cleaver Blade	BI-07
Electrode	EI-23
External Power	DC 12V available for car cigar jack
Sleeve	S-160 (60mm), S-140 (40mm)
Sleeve Clamp	-
Sleeve Loader (2ea)	-
Optical Fiber Holder	HS-250, HS-900, HS-2.5F, HS-IN, HS-SC/FC, HS-ILC, HS-ST, LS-900(Loose tube)
SOC Connector	SC, LC, FC, ST (refer to FTTx solution catalogue)
Wifi Card	WBM-01


III. Product Description



3.1 Function Buttons


Button	Description
	<p>To turn the power on/off-press button for about 1.0 second. Press for about 1 second in POWER ON status, the LCD monitor turns off. Turn off the power after 2~3 seconds.</p>
	<p>To call the main menu screen.</p>
	<p>To execute splicing command.</p>
	<p>To return to the initial screen. To initialize the splicing function.</p>
	<p>To activate the sleeve heater.</p>
	<p>To supply power to the Automatic Fiber Stripper heater.</p>

3.2 Part name of Swift K33A

3.2.1 Components







3.2.2 Swift K33A Auto Stripper


Swift K33A automatic fiber stripper automatically carries out an accurate stripping of the coating of single- and multi-mode fibers. Featuring excellent tensile force of fiber, the automatic stripper strips up to 28.0mm in length without damaging the surface of fiber. Read the user manual sufficiently to maintain the best performance of the unit.

- ⚠ Be careful not to wet the equipment.
 Maintain the unit in a clean condition at all times because many of splicing problems are caused by dust or moisture.
 Keep and use the unit at room temperature as it could be deformed by heat.
 Keep the equipment from being shaken or physically impacted as it could be broken.
 Never use organic solvents such as acetone except alcohol to clean rubber part of the equipment.

3.2.2.1 Specifications

No	Subject	Description
1	Applicable Fiber Diameter	125 μ m
2	Applicable Cable Diameter	250 μ m, 900 μ m
3	Strip Length	Max 28.0mm
4	Heating Time	0 ~ 15 sec
5	Heat Temp. Range (HEATING TYPE)	60 °C ~ 150 °C
6	Tensile Force after Stripping	4kgf

3.2.2.2 Configuration and name of each part



< Front View >




< Control Panel >

3.2.2.3 Operation Procedure (Fiber stripper)

- i. Warm up the thermal stripper after applying power to the control area.
Open thermal stripper cover and slide cover for preparation.



< Control Panel >



< Front View >

- ii. Place fiber into the holder as shown below pictures. The minimum stripping length should be longer than 25mm.



< 900um Fiber >

- iii. Mount the holder containing the fiber onto the slider and close slide cover.



< 900um Fiber >

- iv. Once the thermal stripper cover is closed, the fiber is heated up for a pre-defined time and the coating is stripped by moving the slider.


- v. When stripping is completed, open the slide cover and detach the holder containing the stripped fiber. The slider part moves to the initial position as thermal stripper cover is opened.
- vi. Remove any remaining coating residue from thermal stripper and blade areas using a soft brush for next operation.
Be careful in handling blade part which is very sensitive.



3.2.2.4 maintenance

[Replacement & Adjustment of Blade]

- i. Remove worn out blade by unscrewing fixing bolts as shown below picture. At this time, move the slide part to the left hand side.



- ii. Place new blades in the reverse manner of removing.
(Two blades as a pair at top and bottom)
Make sure that both blades fit tightly in place in order to achieve a good strip result.

[Handling and storage]

- Be careful of using, handling or storing principal parts including blades, heater, etc as they are closely related to the equipment's operation life.
- Do not apply unnecessarily weight or physical impact in handling the equipment.
- Keep the principal parts of the equipment in a clean condition always.
- Keep it clean and in a case when not using, which will increase the life of the equipment.

3.2.3 Swift K33A Cleaner

The alcohol dispenser in the Swift K33A has a limited capacity; the alcohol pump can be removed and refilled with cleaning fluid.



<Assembled>



< Disassembled >

⚠ Be careful not to wet the equipment.

Maintain the unit in a clean condition at all times because many of splicing problems are caused by dust or moisture.


Keep and use the unit at room temperature as it could be deformed by heat.

Keep the equipment from being shaken or physically impacted as it could be broken.

Never use organic solvents such as acetone except alcohol to clean rubber part of the equipment.

i. When cleaning, press down on the alcohol dispenser 2 or 3 times, using cleaning cotton (wipe) as shown in the picture below.

At this time, to avoid splashing the alcohol please cover the top part of dispenser with cleaning cotton and push it.



ii. If no alcohol is discharged, open cap and refill the dispenser.

Add alcohol after completely removing it from the Swift K33A body by pulling upward. It is connected to the body by magnet.





iii. The recommended cleaning fluid is MCC-POC03M.

3.2.5 Swift K33A Cleaver

The cleaver is designed to cleave the fiber at a 90 degree angle. For the best result, following requirements should be met.

- i. The coating of fiber shall be cleanly stripped.
- ii. The fiber shall be properly placed on the holder upon cleaving.
- iii. The physical condition and height of the cleaver blade shall be adequately maintained.



Be careful not to wet the equipment


Maintain the unit in a clean condition at all times because many of splicing problems are caused by dust or moisture.

Keep and use the unit at room temperature as it could be deformed by heat. Keep the equipment from being shaken or physically impacted as it could be broken.

Never use organic solvents such as acetone except alcohol to clean rubber part of the equipment.

3.2.4.1 Operation Procedure (Fiber Cleaver)

- i. Open cover and set the holder containing stripped fiber into the cleaving position. Check whether the fiber is lying in place. Use the chip-box located at the right side of the body.




- ii. Press the cover to cleave the fiber.



- iii. Open the cover and check the result.

- iv. Take out the cut fiber and holder. Be careful not to contaminate the fiber with dust or foreign substance. The fiber shards are collected in the slide-type chip-box placed at the side of Swift K33A body.



3.2.5 Swift K33A Sleeve-heater


The sleeve heater is designed to strengthen the fiber splice.

To ensure maximum reinforcement the following conditions must be met.

- i. After splicing the fiber splice must be visually perfect.
- ii. The fiber and sleeve must be placed correctly in the heater, failure to place the sleeve and fiber in the correct position can result in incorrect heating and possible damage to the splice joint.
- iii. When splicing, the heater cover cannot be left open, it must be in the fully closed position.

3.2.5.1 Specifications

No	Subject	Description
1	Applicable Cable Diameter	250μm, 900μm, 2.0~ 3.0mm
2	Sleeve Length	32mm(standard)
3	Sleeving Time	20~35 sec
4	Heat Temp. Range	130°C ~ 200 °C



⚠ Be careful not to wet the equipment.

Maintain the unit in a clean condition at all times because many of splicing problems are caused by dust or moisture.

Keep and use the unit at room temperature as it could be deformed by heat.

Keep the equipment from being shaken or physically impacted as it could be broken.

Never use organic solvents such as acetone except alcohol to clean rubber part of the equipment.

3.2.5.2 Operation Procedure (Heating Sleeve)

[Sleeve Procedure]

- i. As shown in the picture below, apply power to the control panel and open the cover of the heater to prepare.




<Control Panel>



<Heating Sleeve>

- ii. Set the sleeve tube to the area of arc-fused fiber that needs to be reinforced and place the fiber inside the heater. The connector type should be set to the right-most position so that sleeve tube moves the heater as closely as possible.




Sleeve Tube

- iii. Activate the heater after placing the fiber. Cooling fan is run to cool the tube 20 seconds after heater activation.



- iv. Open the cover when cooling is completed and take out the reinforced fiber.




3.2.5.3 Maintenance

[Handling and storage]

- Be careful in using, handling or storing principal parts including blades, heater, etc as they are closely related to the life of the equipment.
- Do not apply unnecessarily weight or physical impact in handling the equipment.
- Keep the principal parts of the equipment in a clean condition always.
- Keep it clean and in a case when not using, which will increase the life of the equipment.

IV. Operation

The initial screen is displayed as below. It is important to choose a right splice mode and heat mode to ensure an accurate splicing result. The basic information of the Swift K33A is displayed on the initial page. Before splice, make sure the appropriate mode is selected.




4.1 Supplying power to the Swift K33A

It is strongly recommended to use the AC adapter (F1-1) and battery (K3360) provided with package. Using a battery other than provided may cause fumes, fire, and damage to the device, personal injury and death.

4.1.1 How to insert and detach the battery



Insert the battery into the battery groove until it clicks.




Please make sure the power is off before removing the battery. Remove the battery by releasing lock lever.


4.1.2 How to charge the battery













Make sure the voltage and frequency and connect the DC cord of the AC/DC adapter to the DC jack of the battery. The LED turns to green when the charging is completed. The battery includes the protection circuit that prevents full discharge and full charge. The supply of power stops once the protection circuit is activated. In order to deactivate the protection circuit and resume feeding power, wait about 10 seconds and connect again the DC cord to the DC jack.


Swift K33A can be charged during operation because the floating charging method is applied. The battery can be also charged with 12V Cigar jack charger.




4.1.3 How to check remaining battery capacity


Press  to check the remaining battery capacity.

Remaining battery amount (Monitor)	Remaining battery capacity display (LED)	Percentage remains
 (5 bars)	 5 LED	80 ~ 100%
 (4 bars)	 4 LED	60 ~ 80%
 (3 bars)	 3 LED	40 ~ 60%
 (2 bars)	 2 LED	20 ~ 40%
 (1 bar)	 1 LED	10%
 (No bar)	 0 LED Nothing displayed	5% or less

 It is strongly recommended that the battery must be charged as remaining capacity reaches to 10 % (1 bar). If not, there occurs the splice loss.

4.2 Turn on the Swift K33A

Press  and hold for about 1.0 second without opening the windshield cover. The initial screen is displayed as below after resetting all their initial functions. It is important to choose a right splice and heat mode to ensure an accurate splicing result. The current splice and heat mode are displayed at the bottom of the initial page.



4.3 Installing the sleeve loader / cooling tray

Get the sleeve loader installed as follows.



Install the cooling tray on the rear side of heater as follows.





4.4 Inserting the fiber into the sleeve

Insert the fiber into the sleeve.



4.5 Optical fiber cleaning and stripping


Do stripping procedure on about 26mm from the end of optical fiber by using Auto Thermal Stripper. And wipe the optical fiber clean with soft cloth or cotton moistened with alcohol.




⚠ Use high quality ethyl-alcohol with higher than 96% purity.

4.6 Cleaving the fiber


- i. Install the optical fiber on Cleaver as shown in the figure below and check optical fiber's state and cleaving length. When optical fiber is not properly installed, problems may be incurred on cleaving procedure.




- ii. Pull down and press the cover to cleave the fiber.
- iii. Lift the cleaving lever and take the optical fiber out.
- iv. Remove the fiber fragments and dispose it in a proper container.

 Please read user manual of the cleaver for more detailed information about the operation of the cleaver.

4.7 Load the fiber to the Swift K33A



- i. Open the windshield cover and optical fiber.
- ii. Put optical fiber between V-Groove and electrode. Be careful not to make the tip of prepared optical fiber bump against other objects.
- iii. Fix the optical fiber with hands to prevent its move and close the clamp with care.
- iv. Install the optical fiber on the opposite side in the same way.
- v. Close the windshield cover with care.


 The better the optical fiber is installed at a proper location, the shorter it takes for alignment.

4.8 Splice

The condition of the fiber can be observed via the image processing system in the Swift K33A. However, the visual inspection is necessary to ensure better splice result. The splicing process starts as soon as the windshields cover is closed in Auto mode.

- i. The fibers loaded in the splicer move toward each other.
The movement stops at the positions after the fiber cleaning arc. Then the splicer checks cleaved angle, end-face quality and dust. If the measured cleaved angle is bigger than the preset limit value or any damage of the fiber is discovered, an error message appears on the screen and the splice process stops. Though no error message appears on the screen, visual inspection on cross section is recommended as the process stops.
- ii. Optical fibers are arrayed core vs core after inspection. Deviation on clad axis and deviation measured on core axis can be displayed on screen.
- iii. After alignment completes, arcing is conducted to splice fibers.
- iv. After splice completes, estimated loss value is displayed on screen. Estimated value of splice loss is subject to various factors related to error. These factors related to error affect estimation and calculation of estimated loss value as well. Calculation of estimated loss is based on factors such as MFD. When estimated loss value exceeds the preset limitation, error message is displayed on the screen. The error message is also displayed when the spliced optical fiber is too thick or thin or when bubbles are generated on the joint. Even when there is no error message displayed, however, it is recommended to conduct sealing yet again when the splice result on screen is considered not good enough.
- v. Splice result is saved as follows.

When splice completes, splice result is automatically saved.




4.9 Swift K33A Sleeve-Heater part

Sleeve heating part of K33A realizes reinforcement of single optical fiber subject to sealing splice. State of sealing splice on optical fiber should be appropriate.

Optical fiber that sleeve tube is inserted to heater should be appropriately arrayed and installed. Heater cover should be closed upon sealing.


Cable diameter	250μm, 900μm, 2.0 ~ 3.0mm
Sleeve length	20 ~ 60mm
Sleeving time	5 ~ 150 sec
Temperature range	130°C ~ 200 °C

- i. Choose the heater mode after the confirmation of the length for the sleeve tube when placing a sleeve tube on a heater.
- ii. Place the spliced point in the middle of the sleeve tube first. Then, checking out the heating part on the heater and place the sleeve tube on right position.


 Choosing improper mode of the heater for a sleeve tube may not shrink the sleeve tube properly. Especially, SOC (Splice-On-Connector) should be placed on the right side edge of the heater in order to line up the right end of the sleeve tube to the right side edge of the heater as shown on the picture below (Right picture). If SOC is placed in the middle or on the left side, sleeve tube of the SOC does NOT shrink.




[Optical Fiber]



[SoC Connector]

- iii. After placing the optical fiber on the heater, press  button to start the heater. (Operation time: about 20 seconds).




- iv. When the heater is complete, open the cover and remove the fiber-reinforced cooling Tray to go to the cooling sleeve.

4.10 Separation of connected optical fiber

- i. Open the cover of sleeve heater.
- ii. Open the windshield cover.
- iii. Hold the optical fiber on the left and open the clamp on the left.
- iv. Open the optical fiber clamp on the right.
- v. Hold the both sides of spliced optical fiber and separate optical fiber from Swift K33A with care.

4.11 Heating for protecting sleeve

- i. Move a splicing point to the center of protecting sleeve. Make the protecting support of sleeve face the bottom.
- ii. Place the protecting sleeve at the center of sleeve heater.
- iii. Hold the both sides of optical fiber and pull downwards as shown in the figure and the heater cover is automatically closed.
- iv. Heating starts by pressing **HEAT**.
- v. LED is turned off when heating completes.
- vi. Open the heater cover and separate optical fiber. Do not touch protecting sleeve or heater right after the heating.
- vii. Conduct final inspection on whether there are bubbles, fragments or dusts on sleeve.





V. Maintenance of splice quality

5.1 Cleaning and Inspection before splice

5.1.1 V-Groove cleaning

When the inside of V-Groove is contaminated, splice quality may deteriorate. Thus, it is important to regularly inspect and frequently clean the V-Groove as follows.

- i. Open the windshield cover.
- ii. Clean the V-Groove using cotton swab moistened with alcohol. Remove the alcohol remaining on V-Groove using a clean and dry cotton swab.
- iii. When a foreign substance is not removed with cotton swab, clean it with the tip of cut optical fiber and then repeat the step above.




5.1.2 Pusher Block cleaning

Contaminations remaining on Pusher Block incur poor splice quality with influence on pusher block location. Thus, it is important to frequently inspect and regularly clean it.



5.1.3 Cleaning the Cleaver

The performance of the fiber cleaver can be deteriorated if the blade or clamp pads of the cleaver are contaminated. In addition, the contamination of the fiber surface or tip can cause higher splice loss. For this reason, it is important to clean both the blade and clamp pads of the cleaver with a cotton swab soaked in alcohol.




5.2 Regular cleaning and inspection

It is crucial to perform inspection and cleaning on a regular basis to maintain the splice quality of the Swift K33A.

5.2.1 Object lens cleaning

Contamination on object lens' surface disturbs distinction of optical fiber core's location and consequently incurs high splice loss. Thus, 2 object lenses should be kept clean at all times. If dust accumulates and is left for long, it may be difficult to remove. Therefore, clean the lens frequently as follows.

- i. Turn the power off before cleaning the object lens.
- ii. Separate the electrode.
- iii. Clean it using a soft cotton swab moistened with alcohol making a circle from the center as in the figure below. Remove alcohol remaining on object lens' surface using a clean and dry cotton swab.



- iv. Surface of object lens should be clean without any line or stain.
- v. Reassemble the electrode.
- vi. Turn the power on; check whether there is any line or stain on the monitor and; conduct Self test.


5.2.2 Blade replacement and blade mode (Rotating / Locking)

Blade change


If the cleaver does not properly cleave the fiber, rotate the blade as follow the instructions. On the blade gear, the channel (cleaving position) from 1 to 24 is marked. When it does not cleave the fiber properly, clean the surface of rubber pad with the alcohol-soaked cotton swab. (But when clean the rubber pad, do not use acetone or solvent.) And if cleaver still does not cleave properly, it means the blade is fully used, operators are required to change the cleaving position by the following order.

[Blade Replacement]


- i. In order to replace blade, disassemble chip collector assembly and rear pusher. Open the cover as shown picture and press the pusher pin to move slider to forward.



- ii. Remove blade pin completely using (-) driver.




- iii. Remove old blade with blade gear from body and replace new blade with blade gear. In here reassembling should be done in a reverse order of disassembling. At this time, especially be careful not to damage the blade. Check the blade operating condition with cleaver cover.




[Blade Mode (Rotating / Locking) Change]

- i. Blade rotating mode.

Initial setting mode will be set as shown picture (Rotation mode).




- ii. Adjust gear pusher position after loosen Set-screw as shown picture.



- iii. Blade locking mode.


When the blade is used without rotating.




5.2.3 Electrode replacement

It is recommended to replace electrode after using 18,000 times. If the actual number of arc discharge exceeds the replacing cycle, a message for electrode replacement is displayed on the screen. Without electrode replacement, splice loss increases and tensile force at splicing point weakens.

- i. Turn the power off when replacing electrode.
- ii. Turn the power on and conduct electrode stabilizing.





- iii. Remove the electrode block and the electrode.



- iv. Clean the electrode carefully using soft cotton swab moistened with alcohol and then install it.
- v. Turn the power on and conduct electrode stabilizing.

VI. Menu

There are 9 sub menus in the main menu. To call a main menu, press . It can be clicked the screen. The main menu is as below.



■ Splice

- ✓ Del: delete splice mode.
- ✓ Replace: select a splice mode from database, replace it.
- ✓ New: add a new mode from database.
- ✓ Edit: edit a splice parameters.
- ✓ Select: select a splice mode for operation.
- ✓ Cancel: close menu window.

■ Heater

- ✓ Del: delete heat mode.
- ✓ Replace: select a heat mode from database, replace it.
- ✓ New: add a new mode from database.
- ✓ Edit: edit a heater parameters.
- ✓ Select: select a heat mode for operation.
- ✓ Ccancel: close menu window.

■ Auto Stripper

- ✓ Del: delete Stripper mode.
- ✓ Replace: select a Stripper mode from database, replace it.
- ✓ New: add a new mode from database.
- ✓ Edit: edit a Stripper parameters.
- ✓ Select: select a Stripper mode for operation.
- ✓ Cancel: close menu window.

■ History

- ✓ Display memory: display a splicing data and image.
- ✓ Clear Memory: erase the whole data.

■ Option

- ✓ Default: Auto, Pause, Auto Heater
- ✓ Lock: Splice Lock, Heat Lock, Clear memory Lock, Password Query
- ✓ Password: change a password.

■ Calibration

- ✓ Arc Calibration: calibrate an arc power.
- ✓ Diagnostic Test: test an state of the Swift KR12A.
- ✓ Dust Test: test a dust in optical path.
- ✓ LED Test: test a LED brightness.
- ✓ Motor Drive: drive a motor manually.

■ Electrode

- ✓ Electrode Caution: set a caution message for replacement
- ✓ Electrode Used: display an arc count number.
- ✓ Electrode Replace: display an warning message.
- ✓ Electrode Stabilize: stabilize an arc discharge current.
- ✓ Clear Arc Count: erase an arc count number.

■ Setting

- ✓ Language: select a language.
- ✓ Date: set a current date & time.
- ✓ Power Save: set a sleep function of the Swift K33A.
- ✓ Buzzer: change a buzzer volume.
- ✓ LCD Brightness: change a monitor brightness.


■ Information

- ✓ Maintenance Info: display a date for maintenance.
- ✓ Sensor Value: display a temperature, pressure and humidity.
- ✓ Program Ver: display the version.
- ✓ Help: display the help contents as below.
 - The names of parts
 - Clean and Inspect
 - Warnings
 - A/S Contact List


Popup Menu

The pop-up menu is new feature of the Swift K33A. The purpose of the pop-up menu is to allow quick access to frequently used modes like splice mode and heat mode. The user can access the pop-up menu in various ways.


[How to call a POP-UP Menu]



- i. Press "Splice" for splice pop-up menu in the initial Ready state.







- ii. Press "Heater" for heat pop-up menu in the initial Ready state.



iii. Press  for initial Ready state.




- Menu: same function with .
- Set: same function with .
- Heat: same function with .
- Auto Stripper: same function with .

[Splice POP-UP Menu]

■ How to add


- i. Press "Splice" for splice pop-up menu in the initial Ready state.



- ii. Select Empty slot.




- iii. Select the splice mode.




■ How to delete

- i. Click .




- ii. Select mode to be deleted.




[Heater POP-UP menu]

■ How to add


- i. Press "Heater" for heat pop-up menu in the initial Ready state.



- ii. Select Empty slot.




- iii. Select the heat mode.




■ How to delete

- i. Click .



- ii. Select mode to be deleted.




6.1 Splice

To import splice mode, press **MENU** and select “Splice” menu by touch. It displays a screen to select splice mode as follows. The selecting screen is equipped with various splice modes to facilitate a user’s easy selection and use of splice mode. In addition, splice mode can be expanded and saved up to 300 units. These splice modes are classified into general mode and user mode.

■ General splice mode: No. 1 ~ 35

■ User splice mode: No. 36 ~ 300



[Outline of splice mode]


Splice mode	Description
SM	It is a mode for basic SM optical fiber. MFD of single mode optical fiber is about 8~10um at 1310nm wavelength.
NZ	It is a mode for NZDS optical fiber. MFD of NZDS optical fiber is about 9~10um at 1550nm wavelength. WDM optical fiber can also be spliced on this mode.
DS	It is a mode for DS optical fiber. MFD of DS optical fiber is about 7~9um at 1550nm wavelength.
MM	It is a mode for MM optical fiber. Core diameter of MM optical fiber is about 50~62.5um.
Other	Other splice modes are saved on database of Swift K33A. New splice modes are currently being updated. Therefore, we recommend that users keep upgrading the equipment regularly by contacting UCLSWIFT.

6.1.1 Del

Firstly select the splice mode; click “Del”, the selected splice mode is deleted.
The splice mode from No.1 to No.35 can't be deleted.

6.1.2 Replace


Click “Replace”, then the splice modes stored in memory is displayed on the screen.
Select the splice mode to be replace, click “OK”. The selected splice mode replaces the last blank mode.



The splice mode from No.1 to No.35 can't be replaced.

6.1.3 New

Click "New", then the splice modes stored in memory is displayed on the screen. Select the splice mode, click "OK". The selected splice mode is added the last blank mode.



The splice mode from No.1 to No.35 can't be added.

6.1.4 Edit

Click "Edit", then the splice parameters is displayed on the screen. Select parameters, adjust it for proper operation.



[Editable parameters in mode]

Set value	Description	General mode	User mode
Optical fiber type	It displays the list of splice mode saved on sealer data to facilitate selection of a proper mode to use. Among splice modes saved on database, it copies a similar splice mode to use editing function.	Editable	Editable
Mode title 1	Mode title 1 is to indicate splice mode within 11 letters at maximum.		
Eccentricity adjustment function	When arraying optical fiber by using eccentricity adjustment function, it sets offset ratio of axis.	Non Editable	
Automatic power	The closer it is arrayed to the core center with fewer errors , the quicker and better the discharge is done.		
Tensile force test	It conducts tensile force test after splice.		
Cutting angle limit	It sets cutting angle's error bound.	Editable	
	When either of cutting angles on both optical fiber is outside the bound, error message is displayed.		
Limit on estimated loss value	It sets estimated loss value's error bound.		
	When estimated loss is higher than the bound, error message is displayed.		
Limit on optical fiber angle	When the bending of 2 spliced optical fibers exceeds the set bound, error message is displayed.	Non Editable	
Cleaning discharge amount	A short cleaning discharge is conducted to remove fine dust on optical fiber's surface upon initial stage of optical fiber arrayal. It sets intensity of cleaning discharge.	Editable	
Cleaning discharge	It sets time for cleaning discharge.		

Clearance	Upon final arrayal, it sets clearance of cross section between both optical fibers.	Non Editable	
Clearance location	It sets location of optical fiber spliced at the center of discharge.		
	When MFD of both optical fibers differs, do the sealing procedure through melting the smaller MFD optical fiber more than the bigger MFD optical fiber. To heat the smaller MFD optical fiber more, splice loss can be lowered by moving the clearance location toward the bigger MFD optical fiber at the center of discharge.		
Initial discharge amount	It sets initial discharge amount from the beginning of discharge before optical fiber's advance. If the value of initial discharge amount is too low, the angle of optical fiber's cross section is poor and consequently, offset can be incurred on the axis and if it is too high, optical fiber can be burned too much or made round and consequently, splice loss value can be big.		
Initial discharge time	It sets initial time from the beginning of discharge before optical fiber's advance. If [initial discharge time] is long, it means the same that [initial discharge amount] gets big.		
Overlap	It sets duplication of optical fiber on optical fiber's advance amount. If [initial discharge amount] is weak or [initial discharge time] is short, set the [overlap] somewhat small and if discharge amount is strong and the time is long, set it somewhat big.		
Discharge amount 1	Main discharge can be adjusted in 2 levels. The first level of discharge is [discharge amount 1] and the second is [discharge amount 2]. [Discharge amount] 1 is set in this area.		

Discharge time 1	It sets time for [discharge amount 1].		
Discharge amount 2	[Discharge amount 2] is the second level of discharge. [Discharge amount 2] is set in this area.		
Discharge time 2	It sets time for [discharge amount 2].		
	It sets time for [discharge amount 2]. [Discharge time 2] is generally set as "OFF." It can set the discharge time as a very long time period but when [discharge time 1] and [discharge time 2] exceed 30 seconds, electrode can be damaged.		
Time period for discharge 2 being On	While [discharge amount 2] is on discharge, you can set the discharge amount as ON and OFF in turn. Time period for [discharge amount 2] being On is set in this area. For re-discharge, set the discharge time as "ON" at all times.		
Time period for discharge 2 being Off	It sets time period for discharge of [discharge amount 2] is turned off. When [discharge amount 2] is occasionally stopped, re-discharge can also be stopped. When re-discharge is continuously required, set as "OFF."		
Re-discharge time	It sets re-discharge time.	Editable	Editable
	Within [splice mode edition], it automatically sets to discharge the re-discharge amount with the same intensity as that of [discharge amount 2]. If [discharge amount 2] is set as ON/OFF, re-discharge is automatically changed.		
Pulling splice	When optical fiber is made thin, splice loss is sometimes increased. This pulling function is set as "OFF." The following 3 parameters decide the pulling shape.	Non Editable	
Pulling standby	It designates time period from the last of		

	optical fiber advance amount to the beginning of pulling.		
Pulling speed	It sets optical fiber's pulling speed.		
Pulling length	It sets optical fiber's pulling time.		
Minimum loss	It is the sum of initially measured splice loss value and the increased loss. When splicing a special optical fiber or other optical fibers, high loss may be incurred in spite of the optimum discharge conditions. To match the estimated splice loss and the actual splice loss, the minimum value of actual splice loss should be set.		
MFD Left	mode field diameter Left		
MFD Right	mode field diameter Right		


6.1.5 Select


Click "Select", then the selected splice mode is stored in the memory for operation.

6.1.6 Close

Touch "CANCEL" icon or press  and it goes back to the previous stage.

6.2 Sleeve Heater

In normal operation mode, to call the heater menu, press . Then you can see the heater menu as below. There're already various heater mode and the user can select for proper operation. Also the heater mode will be stored up to 100. Please note that the user can't use the Del and Replace keys and use Edit key partially from mode No 1 to No 40.



[Summary of Heater Mode]

Set value	Description	Others
60mm	Standard 60mm micro sleeve	Sleeve type, mode title 1 and mode title 2 cannot be edited.
60mm IS-60	60mm micro sleeve	
45mm IS-45	45mm micro sleeve	
40mm	Standard 40mm micro sleeve	
S09	45mm sleeve	
S09-C	22mm sleeve for SOC(SC-0.9mm)	
S20	45mm sleeve for 2.0mm optical cable	
S30	45mm sleeve for 3.0mm optical cable	
S30-C	32mm sleeve for SOC(SC-3.0mm)	
LC09/20-C	25mm sleeve for SOC(LC-0.9 and 2.0mm)	
ST09-C	28mm sleeve for SOC(ST-0.9mm)	
ST30-C	36mm sleeve for SOC(ST-3.0mm)	

Choose the right mode for each sleeve tube type and SOC. Otherwise sleeve tubes do NOT shrink properly.

- ⚠ For the SOC, operators must use UCLSWIFT standard products. Other company's sleeve tubes may not shrink properly.
- ⚠ Each heater mode heats up at different section of the heater.

6.2.1 Del

Firstly select a heater mode; click "del", the selected heater mode is deleted. The mode from No 1 to 40 can't be deleted.

6.2.2 Replace


Click "Replace", then heater modes stored in memory are displayed on the screen. Select a heater mode, click "OK". The selected heater mode replaces the last blank mode.



The mode from No 1 to 40 can't be replaced.

6.2.3 New



Click “New”, then heater modes stored in memory is displayed on the screen. Select a heater mode, click “OK”. The selected heater mode is added the last blank mode.



The mode from No 1 to 40 can't be added.

6.2.4 Edit

Click “Edit”, then heater conditions stored in memory are displayed on the screen. Select parameters, adjust it for proper operation.



6.2.5 Select


Click “Select”, then the selected heater mode is stored in the memory for operation.

6.2.6 Close

Click “Cancel” to go to the previous menu.

6.3 Auto Stripper menu

In normal operation mode, to call the Stripper mode, press **MENU**. There're already various Stripper mode and the user can select for proper operation. Also the heat mode will be stored up to 100. Please note that the user can't use the Del and Replace keys and use Edit key partially from mode No 1 to No 13.




6.3.1 Del

Firstly select the Stripper mode; click "del", the selected heat mode is deleted. The mode from No 1 to 13 can't be deleted.

6.3.2 Replace


Click "Replace", then Stripper mode stored in memory are displayed on the screen. Select the Stripper mode, click "OK". The selected Stripper mode replaces the last blank mode.



The mode from No 1 to 13 can't be replaced.

6.3.3 New

Click "New", then Stripper mode stored in memory is displayed on the screen. Select the Stripper mode, click "OK". The selected Stripper mode is added the last blank mode.



The mode from No 1 to 13 can't be added.

6.3.4 Edit

Click "Edit", then Stripper mode conditions stored in memory are displayed on the screen. Select parameters, adjust it for proper operation.



The Stripper mode from No.1 to 13 can't be edited.


6.3.5 Select


Click "Select", then the selected Stripper mode is stored in the memory for operation.

6.3.6 Close

Click "Cancel" to go to the previous menu.



6.4 History


In normal operation mode, to call the history menu, press . Then you can see the history menu as below. There're already various functions to display data and image also copy such data to USB memory.



6.3.1 Display Memory



The 10,000 both splice loss data and image can be stored and the user can see them.

Each page has 500 loss data and splice image, click   to move the page. After choosing a data with scroll bar, click View to see.




6.3.2 Clear memory

Clear memory erases the whole data.



6.5 Option


In normal operation mode, to call the option menu, press **MENU**. Then you can see the option menu as below. There're already various functions and whatever the user can select for proper operation.



6.4.1 Default

Default is composed of 4 sub check boxes.


To activate a Default menu, check a check box.



Parameters	Description
Auto splice	Do splice process automatically.
Pause 1	It temporarily stops after first arrayal completes. Press SET and it goes to the next step.
Pause 2	It temporarily stops after clad arrayal completes. Press SET and it goes to the next step.
Auto Heat	Power on sleeve heater automatically after splicing process.

6.4.2 Lock


Default is composed of 4 sub check boxes. To activate a Default menu, check a check box. Also it is possible to limit the modifications with respect to the total splice mode, heat mode, and internal memory data by setting up a password. You have to remember the password. If you forget the password, the device has to be brought to the UCLSWIFT Co.,Ltd. to fix it.



	Test item	Description
1	Splice Lock	Lock the modification of the splice mode.
2	Heat Lock	Lock the modification of the heat mode.
3	Clear memory Lock	Lock the modification of the memory.
4	Password Query	To call a password window. The initial password is "1234".

6.4.3 Password

Set up a new password as follow.



- i. Enter a current password.
The initial password is "1234".





- ii. Enter a new password. The new password can be entered within 4 ~ 12 digits.



- iii. Confirm a new password.





- If an incorrect password is entered or you press a wrong button, the screen moves to upper level.



- You have to remember the password. If you forget the password, the device has to be brought to UCLSWIFT Co., Ltd to fix it.


6.6 Calibration


In normal operation mode, to call the calibration menu, press . Then you can see the calibration menu as below. There're already various functions to arc test, diagnostic test and motor drive test.




6.5.1 Discharge amount calibration


Swift K33A continuously checks change in temperature and air pressure through each sensor. Based on such data, discharge amount is automatically calibrated. Change in discharge amount due to electrode abrasion or optical fiber's splice, however, is not automatically calibrated. The central axis of discharge can also be moved leftwards or rightwards with numerous discharge. In this case, discharge amount calibration is required.




- Arc calibration is a function to change the value of arc discharge voltage. It is used for the computation program for splicing. In addition, the calibration value of arc discharge cannot be changed in the splice mode.
- Upon discharge amount calibration, SM optical fiber should be used.
 - i. Place the SM fiber to splicer
 - ii. Click "  ".




- iii. Result similar to following is displayed on the screen when measuring is completed.



- iv. The calibration can be stopped by pressing  even if it has not completed.

6.5.2 Diagnostic Test

Self test is a function to facilitate dust test, LED test and motor test and calibration at a time.



	Test item	Description
1	Dust test	Refer on Dust Test, without fiber.
2	LED test	Refer on LED Check, without fiber.
3	Motor test	Refer on Motor Test, without fiber
4	Heater test	Refer on Heater Test, without fiber

6.5.3 Motor Drive

It checks the operating status of the motor manually.




- i. Place the fiber in the splicer.
- ii. Click "Motor Drive".

- iii. Touch screen to change motor selection. The name of the selected motor is displayed at the top left on the screen.
- iv. Operate the motor in a direction wanted by touching arrow icons at the bottom.

Motor		
ZL/ZR	ZL/ZR Move forward	ZL/ZR Move backward
S	Move step by step press a button.	
M	Move while pressing a button.	


6.5.4 Motor calibration


Motor setting is set on sealer as default but depending on motor setting location, splice speed may slow down. If speed slow down during the splice operation or any abnormality is incurred on entering position, motor setting can be automatically calibrated through this function.



- i. Put optical fiber on sealer.
- ii. Select "Motor calibration" by touching it.
- iii. If an error message is displayed after testing, contact to UCLSWIFT immediately.
- iv. End the calibration by pressing .

6.7 Electrode


In normal operation mode, to call the Electrode menu, press . Then you can see the Electrode menu as below. It is necessary to regularly check and clean the electrodes because they are worn out. The silica oxidized substances is deposited as the electrodes go through numerous times of splices. There're already various functions to arc count, replace time and other.




6.6.1 Electrode Stabilize

Sometimes, surrounding environment may cause the occurrence of irregular arc discharge or splice loss increase. In particular, since it takes a while until discharge is stabilized when the splicer is in lower or higher location, you have to keep adjusting the discharge until the electrodes are stabilized. Especially after installing new set of electrodes, the user must do Electrode Stabilize as follows.


- i. Place the fiber in the arc fusion splicer.
- ii. Click "Electrode Stabilize".



- iii. Click .




- iv. Perform 45 cycle continuous arc discharge to stabilize the electrodes.
 v. Result similar to following is displayed on the screen when measuring is completed.



- vi. After completing the Electrode Stabilize, ARC Calibration should be performed separately.


6.6.2 Electrode Replace

The recommended replacement cycle of an electrode is 18,000 times use. When the set cycle completes, a message to replace the electrode appears.




6.6.3 Electrode Caution

It determines the arc count for alert message. The recommended replacement cycle of an electrode is 18,000 times use.





6.6.4 Electrode Used

It displays the used arc count.




6.8 Setting

In normal operation mode, to call the Setting menu, press . Then you can see the Setting menu as below.



6.7.1 Language

It sets a language to be displayed on the screen.




6.7.2 Date

It sets the date and time in the calendar.




6.7.3 Power Save

It is an important function in terms of energy efficiency. When the Swift K33A operates with a battery, we recommend activate this function to increase your working time.




6.7.3.1 Monitor


The LCD will be automatically turned off, if you don't operate the Swift K33A for a setting time. The monitor is turned on again when you press any button.



6.7.3.2 Splicer



The Swift K33A will be automatically turned off, if you don't operate it for a time set.

The Swift K33A is turned on again only when you press .




6.7.4 Volume

To adjust the buzzer volume.





6.7.5 LCD Brightness

To adjust a monitor brightness.




6.9 Information

In normal operation mode, to call the Information menu, press . Then you can see the Information menu as below. There is some information for your maintenance.



6.8.1 Maintenance


Click "Maintenance Info", following information is displayed.



Item	Description
Produce date	The date when equipment was manufactured. (year, month and date).
Electric number	Arc discharge count since the replacement of the electrode.
Total electric number	Total arc discharge count since its first operation.
Last maintenance	The date when the device was maintained most recently.
Next maintenance	The date when the device will be maintained next time.
Serial number	The unique serial number given to the device.

6.8.2 Sensor

Click “Sensor”, following information is displayed. The splicer consists of various sensors including temperature, pressure and humidity.



6.8.3 Version



Click “Version”, following information is displayed.

The version can be easily upgraded by connecting to PC and using Data Sync program (PC Program).



6.8.4 HELP

Click "HELP", following help is displayed.




Item	Description
The Name of Parts	The main part of the Swift K33A
Clean and Inspect	How to clean and inspect
Warnings	Warnings
A/S Contact List	Service contact point

VII. Error message

7.1 Too Dirty Fiber

It is displayed when the fiber prepared for splice is contaminated more than normal status.

How to: Reset the fiber after cleaning.




7.2 Replace the optical fiber

It is displayed when the fiber is not placed in the middle of the electrodes and V-groove or the objective lenses or reflection mirror is contaminated.

How to: Press **RESET** and place the fiber in the middle of the electrodes and V-groove.

How to: Check the condition of the lenses and reflection mirror and remove any dirt.




7.3 Too long Fiber

It is displayed when the fiber is placed too close to the electrode, the lenses or reflection mirror is dirty or LED light is not bright enough.

How to: Press **RESET** and place the fiber again.

How to: Remove dust and dirt from the lenses and reflection mirror.

How to: Conduct an LED test. If an error occurs, contact UCLSWIFT Co., Ltd.




7.4 Fiber Over Angle

It is displayed when the measured cleaving angle of the fiber is greater than the limit.

How to: Reset the fiber after checking the condition of the cleaver.

How to: Check the value of the cleaving angle.



7.5 Loss is higher

It is an error message generated when estimated loss value is higher than the preset loss factor limit.

How to: Check the loss factor limit.



7.6 Optical fiber is thin

It is an error message generated when optical fiber sealing part becomes thinner than the standard after sealing.

How to: Make adjustment to shorten the pulling length of pulling splice. Check whether discharge amount or discharge time is set as too big or too long respectively.

7.7 Optical fiber is thick

It is an error message generated when optical fiber sealing part becomes thicker than the standard after sealing.

How to: Reduce the overlap set value. Check whether discharge amount or discharge time is set as too small or too short respectively.

7.8 Core bubble error

It is displayed when bubbles or dots exist in the spliced part after completing the splice.

How to: Check the condition of the cleaver.

How to: Clean the V-groove.

How to: Check the condition of the electrode.

7.9 Error on cut surface on left, right or both

It is an error message generated when the cut surface of optical fiber is of poor quality.

How to: Check the state of optical fiber cutter. Cut the optical fiber yet again.

VIII. How to deal with splicing problems

8.1 When the splice loss is too high

- It may have been caused by dirt or dust on the surface of fibers.
 - Carefully clean the surface of the fibers.
 - DO NOT clean the optical fiber after cutting to prevent dust from being gathered on optical fiber's cross section.
 - DO NOT push in the optical fiber when putting it on V-Groove. Optical fiber should be placed from top to bottom V-Groove.


- The arrangement of the fibers can be interrupted by the dirt in the V-groove.
 - Keep the V-groove clean at all times.

- Bad electrodes
 - Replace the electrodes. The tips are bent or contaminated if they are worn out.

- Improper arc discharge or arc discharge time.
 - Check the set values of arc discharge amount and arc discharge time and reset them, if necessary.
 - The machine is delivered after being set to the most optimized values from the factory.

- Inappropriate splice mode
 - Check if the proper splice mode for the fiber has been selected.


8.2 Abnormal operation of arc fusion splicer

- The alignment motion is repeated.
 - Open and close the windshield cover again.
 - Rest the system by pressing  when an error occurs by opening the windshield cover. Turn off the power and contact UCLSWIFT Co., Ltd.

- The error message of “Too Long Fiber” appears repeatedly.
 - Reset and turn off the power. Contact UCLSWIFT Co., Ltd.

IX. Q & A

9.1 Power

- Unable to turn off the power by pressing  .
 - Press the switch and hold it for about 1 second and release the button when the monitor is turned off.

- Unable to splice as number of times as the splicer normally does with the battery that has been fully charged.
 - If the power saving mode is not activated, the battery runs out quickly. Please refer to [Setting Menu] for more information. If the battery has not been used for a while, charge it again until it is charged fully.
 - Use a new battery if the current battery was used for a long period of times and its suggested lifetime is passed. Since the battery works based on chemical reactions, power generated decreases at a low temperature and, in particular, it runs out very quickly when the temperature is below zero. Also, the battery runs out fast when it is used at a high temperature because the power consumption increases. If you cannot charge the battery fully, do as instructed below.

- LED is not turned on while charging the battery.
 - Disconnect the AC power cord from the charger and connect the DC cord to the charging jack. Connect the AC power cord in 10 to 15 seconds. The LED of the battery is turned on red and charging begins.

- Remaining battery is not indicated.
 - Charge the battery.

- Remaining battery is not well displayed.
 - Remaining battery display is for reference.

9.2 Splice

- When an error message appears on the screen.
 - Refer to the [Error message list] for detailed information.
- Irregular or higher splice loss.
 - Clean V-Groove, V-Block, reflector and object lens by referring to [Maintenance of splice quality]. Replace electrode by referring to [Electrode replacement]. Refer to the “High estimated loss” from [Error message list].
 - If optical fiber warps or is bent, place the optical fiber’s bent direction to face the bottom. Splice loss varies depending on cutting angle, discharge condition and cleanliness level of optical fiber. Splice loss is still high or irregular even after implementing the above recovery measures, contact to UCLSWIFT. Annual maintenance is required to keep splice quality.
- Monitor is turned off suddenly.
 - Press any key and check [Monitor Power Save].
- The power of the splicer is turned off suddenly.
 - Turn on the splicer again and check [Splicer Power Save].

- Unable to change arc discharge amount and time.
 - On SM, NZ, MM or AUTO mode, either discharge amount or discharge time cannot be changed. Implement [discharge amount calibration], and the discharge amount on these modes is properly maintained. When used on another mode, discharge amount and discharge time are automatically set to prevent their alteration.


- How to set pause.
 - Refer to [Option Menu].

- How to indicate cutting angle, optical fiber's angle and core/clad deviation.
 - Refer to [Option menu].



- Difference between estimated splice loss and measured splice loss.
 - The estimated splice loss is just a result from computation so it has to be used for reference only.

9.3 Sleeve heater

- The sleeve heater does not give sufficient shrinkage.
 - Increase the duration of heating time. Refer to [Heat Menu] for more information.

- The sleeve heater is overheated
 - Stop the operation of the heater by pressing . Turn off the power and contact UCLSWIFT Co., Ltd.
 - When the sleeve is not separated from the heating plate, use a cotton swab or a similar object to this to push or remove the sleeve.

- How to initialize the heating condition in the heat mode.
 - Refer to [Heat Menu] for more information.

- How to cancel the heating process.
 - You cannot cancel the heating process by pressing .
Press  one more time to cancel it.

9.4 The others

- How to lock “Splice”, “Edit” or heat mode.
 - Refer to [Lock Menu] for more.

- Arc amount is not changed after performing [Arc Calibration].
 - The internal standard discharge amount is calibrated. Therefore, discharge amount of each splice mode does not change.

- If you forget the password.
 - Contact UCLSWIFT Co., Ltd.

X. Warranty period and service

Limited Liability

UCLSWIFT warrants its products against defects in material and workmanship. Under normal use and service, every hardware portion of the products will be free from physical defects in material and workmanship during the warranty period, or the product will be repaired or replaced as determined solely by UCLSWIFT. Customers will be charged for the repair of the machine even if in-warranty period, if such defect or damage occurred as a result of.

- i. Natural disaster(s)
- ii. Applying over-voltage
- iii. Customer's mishandling
- iv. Customer's misuse without following instructions or operation procedures provided by this user manual
- v. Expendables (including electrode)

10.1 Information required for repair

Before sending the splicer to us, it is necessary to contact UCLSWIFT Co., Ltd first.

- i. Give us following information by attaching paper on the product.
(Name, Department, Company, Address, Contact information, FAX, E-MAIL)
- ii. Product's serial number
- iii. Product's state and problem incurred, Information on error message
- iv. Product handling with disregard on working procedure or directions written on instructions for use

10.2 Transport

The Swift K33A is high precision equipment, so it is required to transport after keeping it in a safe case to protect it from humidity, vibration and physical shock. In case of request for repair, it must be in the case along with its parts before its transport.

10.3 Repair

Any data saved in the memory including splice results and splice modes may be deleted as a result of repair.

Products Warranty

Name of product		SWIFT K33A	
Production Number			
Date of purchase			
Customer	Name	Telephone	
	Address		

Limited Warranty

1. This product is manufactured under strict quality management and inspection processes.
2. UCLSWIFT Co., Ltd. warrants this product against defective materials and workmanship for a period of one year from the date of purchase. However, this warranty does not cover a damage or failure caused by or attributable to a reason for Exclusion and Limitations even if the equipment is still under warranty.
3. This warranty card has to be presented when the product is repaired.
4. The arc fusion splicer is high precision equipment, so it is required to transport after keeping it in an exclusive carrier case to protect it from humidity, vibration and physical shock.

Exclusion and Limitations

This warranty will not cover a damage or failure and charges (repairing charge + part + travel expenses) will apply even if the equipment is still under warranty, if such damage or failure has occurred due to or when

1. Natural disaster.
2. Applying over-voltage.
3. Customer's mishandling.
4. Customer's misuse without following instructions or operation procedures provided by this user manual.
5. The stamped seal is broken or damaged.

❖ When you require maintenance or repair service, please contact the service center or the dealer you purchased the machine.

